# **Specification**

Model	Z-AHD20A200M	
Image Sensor	1/2.7" OV 2.1MP CMOS Sensor	
Resolution	1080P	
Signal System	PAL / NTSC	
Minimum Illumination	0.001 Lux/F1.2	
S/N Ratio	More than 50dB	
Synchronous System	onous System Internal	
IR Distance	IR Distance 20 Meters (with Φ5 (12μ) x 24PCSInfrared LED)	
IR Power On	Photodiode AUTO Control	
Video Output	AHD / CVBS	
Functions DWDR, 3DNR,Sense-up,,OSD		
Power/Current	DC12V(+/-10%)/500mA	
Lens	Board Len 3.6mm	
Weather Proof	Weather Proof IP66	
Dimension (mm)	nension (mm) 184(W) x 66(H) x 66(D)	
Weight (g)	800	
Operating Conditions -10~+50□ RH95% MAX		

# ■ Packing List

No	Name	Model	Number
1.	Fixed Bullet Camera	Z-AHD20A200M	1
2.	User Guide	Z-AHD20A200M	1

# **Z-AHD20A200M CCTV Camera**



# Weatherproof IR Bullet Camera





Notes: Thank you for using our ZEBRA Brand product. Before providing power for the camera, please read this manual carefully before use.

We adopt the latest technical of sensor and driver. It owns the characters of high definition and stability, strong anti-jamming, rich and real color. Fixing and using this model are convenient too. It is very good for you to apply to your CCTV system.





Notes: Do not attempt to disassemble the camera. If the camera can not work, please contact local franchiser in your country.

Franchiser:



#### Main Features

## > Auto Gain Control (AGC)

Built-in auto gain control **(AGC)** circuit. The color camera can get high definition picture in low Lux condition.

## > Auto Electronic Shutter (AES)

Built-in auto electronic shutter function. The color camera's AES speed can reach 1/100,000s.

#### > Gama Characteristic

Camera Gama characteristic is 0.45.

#### > Scanning Mode


NTSC or PAL mode.



# Note:

- Power supply must pass safety certification (we suggest our own brand), Its output voltage, current, voltage polarity and operating temperature must match requirement of this equipment.
- Please install lightning protection devices or cut off the power in thunder and lightning conditions.
- To capture high-quality video and pictures, please make

#### **Device connection**



# **Safety instruction**

- 1.Before using the camera ,please read this manual carefully and keep it safely for later use.
- Installation should be proceed by professional service and follow manufacturer's instructions, do not dismantle without authoriza tion.
- 3.In order to prevent sensor ,do not expose lens to intense light source in long time.
- 4.Do not touch sensor directly. Please covers the dustproof cover when the camera is not being used.
- 5.Please use a dry soft cloth to clean the camera. If dirt difficult to clean, use detergent with water and wipe dry the camera.
- 6.Do not install camera under air conditioning's air gate ,or else lens blur with condensation of moisture.
- 7. Please ensure that all electric power sources are turned off when not open, installation, clean, etc operation.
- 8.Please transporting, using and storing the camera in allowable temperature and humidity.
- 9.If the camera was broken, for example power cord or plug damaged, Splash liquid or foreign matter fall into camera, raining, wetting etc., can't work situation, please contact manufacturer or maintenance center (modify and maintenance without perm ission, you must be responsible for the problems).

# **Common Problems and Troubleshooting**

# > No Picture after providing power

May be the power supply voltage abnormity, please check he power supply voltage and pole whether exactitude. Please check all the connecting cable and monitors whether be connected correctly or not.

# > The picture level direction have flowing interference ripples

May be caused by the power supply AC ripples, it need filter the wave of the power supply.

Check the monitor and peripheral equipment's used.

# The picture background color changes continuously The fluorescent lamp's electromagnetic field cause color roll. This is proper phenomenon of the cameras. Reduce the fluorescent lamp numbers or increase the distance between the camera and the fluorescent lamps can

improve it.
Use power supply external sync. camera can solve it.

# > The picture smear too mass

The power supply's voltage unstable. Connecting cables not connect correctly or have high impedance.



#### Note:

• Please note the camera's operating temperature and its using environment requirement. Avoid using the camera at too high or too low temperatures. The operating tem perature is -30~+60°C. (Recommendatory operating tem perature is -10~+50°C.)

• Do not mount the camera near by the radiator or heater.